

**Automatic Pool Cleaner suited for flat
or dish bottom pools**

Ocean Vac 8000



Praher
Ponegggenstr. 5
A-4311 Schwertberg
AUSTRIA / EUROPE

Tel.: ++ 43 / (0) 72 62 / 61 178-0*
Fax: ++ 43 / (0) 72 62 / 61 203
austria@praher.com
www.praher.com

Thanks to the **Ocean Vac 8000** Pool Cleaner, pool maintenance is truly a snap. I simply toss it into the pool and all my cleanup duties are handled automatically. So here I am enjoying the scenery while its scrubbing bristles lift the debris and its highpowered vacuum whirls it all away. Before I know it, I'm home free with a clean and sparkling pool. Now that's cruisin!



- Quality
- Service
- Innovation

Praher - Quality - Service - Innovation

**Automatic Pool Cleaner suited for flat
or dish bottom pools**


Ocean Vac 8000



Suited for flat or dish bottoms

One moving part ensures durability

Cleaning range: 25 cm



Brushes loosen the dirt

Unique bristle-drive propels the cleaner as it scrubs.

Oscillating vortex sucks dirt away

Devours small and large debris without stirring up clouds of dirt.

Designed for versatility

A telepole attachment is available for easy spot cleaning. Optional 2,40 m hose extensions are available for larger pools.

Automatic Pool Cleaner suited for flat or dish bottom pools

Ocean Vac 8000



About your pool and filter system

Hazardous suction. Can trap and tear hair or body parts. Can cause drowning. Do not play with cleaner or hose or apply to body. Do not let children use or play with pool cleaner. Stop pump before attempting to clean unit.

▶ Before installing the cleaner in a vinyl liner pool check liner closely for signs of deterioration or damage from age, chemicals, pool wall damage, etc. If any damage is found have a qualified pool professional make all necessary repairs.

▶ Also if there are any stones, roots, etc. under the liner remove them before installing the cleaner.

▶ Before you install the cleaner make sure you have cleaned the filter (including backwashing) and emptied all baskets.

▶ Always make sure hose and cleaner are full of water before starting pump. Running pump dry may cause overheating and damage pump.

▶ The cleaner is designed to maintain a clean pool. It was not designed for initial cleanup when opening pool for the season.

Safety instructions



This is the safety alert symbol. When you see this symbol on your system or in this manual look for one of the following signal words and be alert to the potential for personal injury.



Warns about hazards that will cause death, serious personal injury or major property damage if ignored.



Warns about hazards that will or can cause minor personal injury or property damage if ignored. Carefully read and follow all safety instructions in this manual and on equipment. Keep safety labels in good condition; replace if missing or damaged.



Oscillator may injure hands or fingers. Stop pump before attempting to clean out pool cleaner head.



Hose can trip or entangle swimmers. Do not allow swimmers in pool while pool cleaner is operating.

About maintenance and care



WARNING

Hazardous suction. Stop pump before attempting to clean pool cleaner.

▶ Keep skimmer basket and pump strainer basket clean and free of debris.


▶ If cleaner jams with large debris (leaves, sticks, etc.), try cleaning debris first from bottom of unit. If this doesn't clear unit remove top swivel assembly (turn $\frac{1}{4}$ turn) and clear the debris from the top.

▶ Remove the pool cleaner from the pool before super chlorinating (shocking) or chemical balancing. Wait at least four hours after the chemical procedure before reinstalling the cleaner.

▶ Make sure that the cleaner's brush bristles don't become deformed during storage. Store the unit so that it doesn't sit on the bristles and so that nothing compresses them.

▶ If possible do not coil the hose. Store it flat and straight.

▶ If necessary to remove oscillator see >Oscillator Removal!<



Automatic Pool Cleaner suited for flat or dish bottom pools

Ocean Vac 8000



More about cleaner and accessoires

1 Hose

▶ The unit includes a 7,3 m hose and a 2,4 m hose which will provide excellent coverage in pools up to 8,0 m.

▶ For pools larger than 8,0 m, add a 2,4 m extension hose.

▶ For pools smaller than 8,0 m, try the hose as it is. If 9.7 m is too much, remove the 2,4 m section and use only the 7,3 m hose.

▶ The hose was designed specifically for the cleaner. Use of a different type of hose will reduce the cleaner's performance.

2 Swivel Assembly

▶ Insert assembly into cleaner body and turn ¼ turn clockwise.

▶ If you attach an unidapt handle to the swivel for manual vacuuming be sure it is a special, floating unidapt handle. Use of a different unidapt handle will hinder the cleaner's performance.

3 Reducer Cone

▶ Adapts hose to skimmer.

▶ Keeps hose in place in skimmer when pump stops.

4 Automatic vacuum regulator

WARNING



Hazardous suction. Can trap or tear hair or body parts. Install vacuum regulator on all high-vacuum systems.

▶ Most systems require vacuum regulator for safe operation.

▶ Regulator provides vacuum relief in case cleaner suction is blocked.


▶ Black rubber diaphragm must always be submerged. If it sucks air the pump will lose prime which could damage the pump.

▶ If pump suction is too weak to give adequate motion to cleaner try removing the vacuum regulator and operating the cleaner without it.

Brush Adjustment



NOTICE: Bristle wear, pool bottom, temperature, etc., will all affect cleaner operation. Use these general guidelines to adjust your cleaner for best performance.



1




2



3



4














Automatic Pool Cleaner suited for flat
or dish bottom pools

Ocean Vac 8000



Installation

| | |
|---|--|
| <p>STEP 1 - Straighten Hose</p> <p>Remove hose from box and lay it out in the sun to straighten.</p>  | <p>STEP 2 - Check Parts</p> <p>Make sure you have all parts to pool cleaner.</p>   Reducer Cone  Hose  Swivel Assembly  Vacuum Regulator |
| <p>STEP 3 Clean System</p> <p>A. While the hose is relaxing, clean and backwash your filter system, skimmer and pump baskets. B. Close main drain if your pool has one. C. Start pump.</p>  | <p>STEP 4 - Assemble Cleaner</p> <p>A. Insert swivel assembly into cleaner body and twist 1/4 turn clockwise to lock. B. Set brush adjuster to '0'. C. Slide long hose cuff over swivel assembly to install hose.</p>  Long Hose Cuff  Swivel Assembly  |
| <p>STEP 5 - Submerge Cleaner</p> <p>A. Start pump. B. Turn cleaner upside down, submerge, and feed hose down side of pool wall to fill hose with water.</p>  | |

Automatic Pool Cleaner suited for flat
or dish bottom pools

Ocean Vac 8000




Installation

For Safety: No Bathers



Hose Connections


Follow drawing that most closely resembles your skimmer installation.



Final Checks (while cleaner is operating)

For Best Results:

1. No ladders.
2. No toys.
3. No floating chlorinators.
4. Close main drain if your pool has one.



Praher - Quality - Service - Innovation

Automatic Pool Cleaner suited for flat or dish bottom pools

Ocean Vac 8000



Troubleshooting guide

Cleaner moves slowly or not at all

1. Backwash and clean filter. Empty all baskets.
2. Clear debris from oscillator or hose.
3. If hoses from skimmer to filter and back to pool are less than 1 1/2" diameter replace with 1 1/2" hoses.
4. Pump in filtration system may be too small. Consult pool professional.
5. Remove vacuum regulator.
6. If your pool has a main drain (floor drain) close it during cleaner Operation.

Cleans only perimeter of pool

1. Install vacuum regulator.
2. Set brush ring adjuster to a higher number.

Cleaner hovers in one area with hose fully extended

1. Hose is too short. It should be approximately 1,5 - 2 m longer than the full length of the pool. Buy a 2,4 m extension hose from your dealer to give adequate length.

Cleaner turns in clockwise circles

1. Set brush ring adjuster to a lower number and only covers one section of pool

Oscillator runs too fast

1. Install vacuum regulator if it isn't already in place (the regulator marked »50« will slow it the most).
2. If your system has a return valve gradually close it until oscillator runs at the desired speed.

Hose keeps coiling up

1. For best results when hose is not in use store it flat and straight. Lay hose out in the sun (flat and straight) for a few hours. Hose is too long - remove 2,4 m section.

Pool not completely clean in four hours

1. Any cleaner may miss a spot. Spot clean pool by attaching a vac-pole (telepole) to cleaner and steering it (see Page 5).
2. Try different brush ring adjuster settings (0 - 4) until the cleaner gives the desired results.
3. The cleaner was not designed to work under all solar covers.
4. Strong winds may interfere with complete cleaner coverage.

Cleaner flips on its side when pump stops

1. This is normal if filter system develops a backpressure surge when the pump stops. The cleaner will right itself when system is restarted.

Hose comes loose when pump stops

1. Use reducer cone in skimmer.

Cleaner sticks to pool bottom or pool main drain

1. Install vacuum regulator with diaphragm marked »50«.
2. Check inner brush ring for excessive wear.